


Extraction Arm accessories



	Description	Original	Telescopic	Standard	NEX HD	NEX MD	Part no.
1	Wall bracket for 2 m (7 ft.) and 3 m (10 ft.) arm				X	X	10372215
2	Wall bracket for 4 m (14 ft.) and 5 m (16 1/2 ft.) arm				X	X	10372722
3	1 m (39 in.) Extension wall bracket				X	X	10512732
4	2 m (79 in.) Extension wall bracket for 2 m and 3 m (7 ft and 10 ft.) arm				X	X	10512832
5	Wall bracket	X	X				10550635
6	1 m (39 in.) Extension wall bracket	X	X				10550735
7	2 m (79 in.) Extension wall bracket	X	X				10550835
8	Spotlight/Fan Switch, 24V, 20W, Original hood *	X	X			X	10551235
	Relay for spotlight part no. 10551235 *	X	X				14374307
8	Spotlight/Fan Switch, 24V, 20W, Metal hood	X	X				10507435
9	Spotlight/Fan Switch, 24V, 20W				X		10512432
8	Spotlight/Fan Switch, 24V, 20W, MD hood *					X	10554635
8	Fan Switch				X		10512532
8	Fan Switch, Metal hood	X	X				10371080
9	Spark protection, Original hood	X	X			X	10551335
9	Spark protection, Metal hood	X	X				10373118
9	Spark protection NEX HD				X		10512632
10	Metal hood with damper	X	X				10321542
11	Damper			X			10500438
12	Silencer for fan	X	X				14502126
12	Silencer for fan				X	X	14502626
13	Wall bracket for silencer	X	X		X	X	14343089

* When using external power 24 V and no Nederman Fan Starter, a relay (part no. 14374307) must be installed between the spotlight and the contactor.